

Mira Thermostatic Shower Instructions

Before switching on, please ensure top control is set to eco mode and bottom control is set between 11 o'clock and 12 o'clock position. Switch on shower, you can then move from eco to high if required. If temperature needs to be increased, please do so slowly and in small increments. This will ensure the shower stays at the correct temperature. Thank you.